
# **Footwear Markings Checklist**





### **Marking Codes on CE Certified Footwear**




Additional protection may be provided and is identified on the product by its marking as below:



HRO Heat resistant outsole compound: shall withstand 300°C for 60s



WR Water resistant footwear



WRU Water resistant upper leather

CI Insulation against cold

FO Fuel oil resistant outsole

HI Insulation against heat

Metatarsal protection: 100J impact energy

Energy absorption of the seat region

CR Cut resistant upper

AN Ankle protection

I Insulating

Footwear that feature slip resistance, are tested according to a set of European standards written into EN ISO 20345: 2011. Footwear which has passed this test will be marked with one of the codes below.

SRA

Slip resistance on ceramic tile floor with dilute soap solution

SRB

Slip resistance on steel floor with glycerol

SRC

Slip resistance on ceramic tile floor with dilute soap solution and on steel floor with glycerol

### **Footwear Information**



It is important that you choose the correct industrial footwear for your specific working environment. We would therefore recommend that in the first instance a risk assessment is carried out to ensure that the correct protection level and style of footwear is selected.

#### Risk Assessment

Assess the risks within the working environment to either remove or protect against the hazards.

This must involve defining the job or work area, recognising the risks, and identifying the correct method of reducing them

i.e. by removing, controlling, or by choosing suitable safety footwear.



#### Safety features include:

- Impact resistant toe caps
- Pierce resistant midsoles
  - Anti-static soles
- · Sole resistance to heat
  - · Resistance to cold
  - Water resistance
- · Resistance to fuel oil
- · Resistance to chemicals
- Slip resistant sole properties



#### **Materials and construction**

There are various methods of attaching the sole of the footwear to the upper material; this has some considerable influence on product selection depending on the environment in which the footwear will be used.

- Direct injection moulding Again a strong construction method used with either one density of polyurethane (known as single density)
  or two densities, either polyurethane or an inner density of polyurethane and an outer density of nitrile rubber (known as dual density).

  Both types provide reduced weight with improved comfort and flexibility, without any compromise in performance.
- Goodyear welted Another traditional form of construction where the sole is stitched to the upper material, again a very strong method, which would generally be slightly heavier in use than the above. Suitable for most dry environments.
- Cemented This is exactly what it suggests; the sole unit is preformed and cemented (glued) onto the upper material creating a strong bond.
  - Cushioned soles when standing for long periods of time.
  - Wellington boot The vast majority of wellingtons in use are direct injection moulded from either raw PVC with varying quantities of
    nitrile rubber or Polyurethane, both types provide excellent flexibility and resistance to chemicals.

## **Footwear Symbols**



200 Joule steel toe cap





200 Joule composite toe cap

Steel midsole protection





Composite midsole protection

Metatarsal protection





Anti Static

Shock absorber heel





Resistant to acids & alkalis

**Energy** absorbant





Washable to 40°C

Resistant to oils





Breathable membrane lining

Heat resistant sole to 300°C





Water resistant leather upper

Slip resistant





3M® Thinsulate lining

Leather upper





Contains European sizes 40 & 45





# **Selecting the Correct Materials**



Selecting the correct materials is critical, especially when contaminants are present. By choosing the correct material the maximum lifespan of footwear can be achieved.

- Nitrile rubber sole for higher temperatures, oil and solvent resistant.
- Polyurethane soles for general purpose use, oil and solvent resistant.
- Water repellent leather uppers where there is an occasional exposure to water.
- PVC, PVC nitrile, rubber and polyurethane uppers where there is long term exposure to water and certain chemical applications.

### **Footwear sizes**

