# Package Contents



Orbi Pro satellite (Model SRS60)



(varies by region)

Rubber feet



Mount base



Mount base screws



Mount cover Wall bracket




Wall anchors with screws (2)



T-bracket with screw



T-bracket screws



## Attach the Mount Base

Attach the mount base and the mount cover for wall-mounting or ceiling-mounting.







# Wall-Mounting





# Ceiling-Mounting





Loosen the screw so that the locking plate can slide. Then tighten to secure to the T-bar.





4



Quick Start

Model SRS60





## Orbi Pro Satellite Overview



- 1 Ring LED (not shown in image)
- Sync button (also used for WPS connection)
- 3 Ethernet ports
- Power On/Off button and Power LED
- DC Power connector
- 6 Reset button

# Sync Your Orbi Pro Satellite

To sync your Orbi Pro satellite with your Orbi Pro router, you can use the NETGEAR Insight app or you can manually sync your satellite.

### Sync Your Satellite With the NETGEAR Insight App

You can use the NETGEAR Insight app to sync your satellite with your Orbi Pro router. For more information about the app, visit <a href="https://www.netgear.com/insight/">https://www.netgear.com/insight/</a>.



 Download the NETGEAR Insight app from the Apple App Store or Google Play Store.





2. Launch the NETGEAR Insight app on your mobile device and follow the prompts.

### Manually Sync Your Satellite With Your Router

You can manually sync your satellite using the **Sync** buttons on your Orbi Pro satellite and router.

- 1. Place the Orbi Pro satellite in a central location for the best WiFi coverage.
- Connect the Orbi Pro satellite to a power source.
  The Power LED on the back of the Orbi Pro satellite lights green. If the Power LED does not light, press the **Power On/Off** button.
- 3. Press the **Sync** button on the back of your satellite, and within two minutes, press the **Sync** button on the back of your router.

The Orbi Pro router's ring LED turns off after the setup is complete.

## Orbi Pro Satellite Sync Information

The Orbi Pro satellite's ring LED lights white while the satellite attempts to sync with the Orbi Pro router. After the Orbi Pro satellite's ring LED lights white, it lights one of the following colors for about three minutes and then turns off:

#### Blue

The connection between the Orbi Pro router and Orbi Pro satellite is good.

#### Amber

The connection between the Orbi Pro router and Orbi Pro satellite is fair. Consider moving the Orbi Pro satellite closer to the Orbi Pro router.

#### Magenta

The Orbi Pro satellite was unable to connect to the Orbi Pro router. Move the Orbi Pro satellite closer to the Orbi Pro router.

### Support

Thank you for purchasing this NETGEAR product.

You can visit <a href="https://www.netgear.com/support/">https://www.netgear.com/support/</a> to register your product, get help, access the latest downloads and user manuals, and join our community. We recommend that you use only official NETGEAR support resources.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à https://www.netgear.com/support/download/.

(If this product is sold in Canada, you can access this document in Canadian French at <a href="https://www.netgear.com/support/download/">https://www.netgear.com/support/download/</a>.)

For regulatory compliance information including the EU Declaration of Conformity, visit <a href="https://www.netgear.com/about/regulatory/">https://www.netgear.com/about/regulatory/</a>.

See the regulatory compliance document before connecting the power supply.

NETGEAR, Inc.

350 East Plumeria Drive San Jose, CA 95134, USA

December 2016

