

Hard-to-find made easu®

5 Pack of Stick on Thermal Pads

HSFPHASECM

DE: Bedienungsanleitung - de.startech.com

FR: Guide de l'utilisateur - fr.startech.com

ES: Guía del usuario - es.startech.com

IT: Guida per l'uso - it.startech.com


NL: Gebruiksaanwijzing - nl.startech.com

PT: Guia do usuário - pt.startech.com


Packaging Contents

• 5x Thermal Pad

Installation



1. Remove the clear plastic backing from the compound to expose the adhesive. Removing the plastic in one quick, smooth motion will ensure that no plastic remains on the adhesive.



2. Place the compound (adhesive side down) to the bottom of the heatsink. Generally, affixing the pad to the center of the heatsink offers the best performance.



*actual product may vary from photos



3. Smooth the back of the compound with downward pressure to ensure a consistent application.



4. Using a single quick smooth motion, remove the wax paper from the compound. Ensure to remnants of wax paper remain.





5. Install the heatsink and fan according to the instructions from the manufacturer.



Ensure that the fit between the processor socket and the heatsink is consistent.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

For the latest drivers/software, please visit www.startech.com/downloads

Warranty Information

This product is backed by a two year warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.