





- For optimal performance, place Game Drive at least 10 cm (4 in) from the PS4.
- Pour des performances optimales, placez le Game Drive à 10 cm (4 po) au moins de la PS4



NWWW.SEAGATE.COM

For customer support, visit www.seagate.com/support/game-driveps4 or call 800-732-4283.

Note: To protect your data, always follow the safe removal procedures for your operating system when disconnecting your product.

To review the details of your drive's warranty, open the Seagate Retail Limited Warranty Statement on your drive or go to www.seagate.com/ retailwarranty. To request warranty service, get information regarding customer support within your jurisdiction (including on compatibility issues with Sony PS4 software version 4.50 or higher), or to obtain information regarding the location of authorized Seagate service centers go to www.seagate.com. To review the end user license agreement applicable to this drive, go to www.seagate.com/ legal-privacy/end-user-licenseagreement.

Seagate and Sony Interactive Entertainment LLC (SIE) exclude all liability for loss of data, loss of profit. or any loss or damage suffered by you or any third party, whether those damages are direct, indirect, consequential,

special, or incidental, as a result of using this product.

FCC DECLARATION OF CONFORMANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference. and (2) this device must accept any interference received, including interference that may cause undesired operation.

CLASS B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to

try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications made to this equipment may void the user's authority to operate this equipment.

WWW.SEAGATE.COM

Pour accéder à l'assistance technique. consultez le site www.seagate.com/ support/game-driveps4 ou appelez le 800-732-4283.

REMAROUE: Pour protéger vos données, suivez toujours les procédures de retrait sécurisé correspondant à votre système d'exploitation lors de la déconnexion du produit.



GAME DRIVE

Add-on storage for PlayStation[®]4 systems

Stockage complémentaire pour systèmes PlayStation 4

FAI SEAGATE © 2018 Seagate Technology LLC. All rights reserved. Seagate, Seagate Technology and the Spiral logo are registered trademarks of Seagate Technology LLC in the United States and/or other countries, "PlayStation" is a registered

trademark of Sony Computer Entertainment Inc. PS4 and PS4 Pro is a trademark of the same company. All other trademarks or registered trademarks are the property of their respective owners. Seagate reserves the right to change, without notice, product offerings or specifications, Complying with all applicable copyright laws is the responsibility of the user.

Seagate Technology PLC

38/39 Fitzwilliam Square

Dublin 2

Ireland

Seagate Technology LLC 10200 S. De Anza Blvd. Cupertino, CA 95014 U.S.A.

Seagate Singapore International Headquarters Pte. Ltd. Koolhovenlaan 1 1119 NB Schiphol-Riik The Netherlands

PN:100841146B 08/18

OUICK START GUIDE GUIDE DE DÉMARRAGE RAPIDE