

Hard-to-find made easy®

# 80mm/92mm/120mm Computer Case Fan with 4-pin PWM connector

FAN8025PWM / FAN9225PWM / FAN12025PWM

DE: Bedienungsanleitung - de.startech.com

FR: Guide de l'utilisateur - fr.startech.com

ES: Guía del usuario - es.startech.com

IT: Guida per l'uso - it.startech.com

NL: Gebruiksaanwijzing - nl.startech.com

PT: Guia do usuário - pt.startech.com

## **Packaging Contents**

- 1 x Case Fan
- 1 x 4-pin Y-Cable

## **System Requirements**

- · 3-pin or 4-pin fan header
- · Mounting location for case fan
- · Mounting hardware



\*actual product may vary from photos

### How to Use

The included 4-pin Y-Cable can be used on systems with only one available 4-pin PWM Fan Header to connect two different system fans. Connect the 4-pin female connector on the cable to the Fan Header on the system board, then connect a 4-pin PWM-enabled fan to the 4-pin male connector (black). A 3-pin or 4-pin fan can be connected to the 3-pin connector (white). The speed of both fans will be controlled simultaneously, based on the PWM signal from the 4-pin connector (black).

## **Specifications**

	FAN8025PWM	FAN9225PWM	FAN12025PWM
Bearing Type	Ever Lubricate Bearing		
Air Flow Rate	9.74 ~ 25.02 CFM	12.78 ~ 39.35 CFM	33.20 ~ 78.41 CFM
Noise Level	< 10dBA ~ 28 dBA	< 10 dBA ~ 25 dBA	< 17.2 dBA ~ 39 dBA
RPM	800 ~ 2500 RPM	700 ~ 2200 RPM	800 ~ 2200 RPM
Material	Plastic		
MTBF	40, 000 hours		
Operating Temperature	-10°C to 70°C (14°F to 158°F)		
Storage Temperature	-20°C to 70°C (-4°F to 158°F)		
Humidity	0 ~ 65% RH		
Dimensions	80.0mm x 80.0mm x 25.0mm	92.0mm x 92.0mm x 25.0mm	120.0mm x 120.0mm x 25.0mm
Weight	86g	96g	118g



#### Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

#### **Technical Support**

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

For the latest drivers/software, please visit www.startech.com/downloads

#### **Warranty Information**

This product is backed by a two year warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

#### **Limitation of Liability**

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.