















User Manual

BOOMPODS

music . anywhere . everywhere

BOOMPODS™ designed in the UK by DT-Design Ltd. All rights reserved ©2013. This product uses BOOMPODS" technology and is covered by international patents, downdraft - IP: 201230133252.3





din .





3.5mm Audio Jack


41

downdraft

Introduction:

Before using your down**draft** speaker for the first time, please take a few moments to read through the user manual.







You can use your downdraft as a wired speaker to increase battery life. Simply connect the 3.5mm line-in cable to your audio source and the Micro USB end to your downdraft speaker (2).

Charging:

To charge, simply connect the USB cable end directly to a PC, laptop or mains USB charger and the Micro USB end to your downdraft speaker (2). The LED (3) on your speaker will turn red whilst charging, and turn off when fully charged. Please note that the speaker will not charge and play at the same time.

Package contents:

- 1 x down**draft** wireless portable speaker
- 1 x Micro USB, 3.5mm audio and standard USB cable
- 1 x user manual

Technical details:

- Max output power: 3W
- Battery capacity: 350mAh 3.7V
- Frequency: 120Hz-15000Hz
- Charge time: 1.5 hours
- Bluetooth range: 10m (open space)
- Bluetooth: 3.0 version + EDR

General quidelines:

Keep away from high temperature or prolonged exposure to direct sunlight. Avoid contact with liquids.

Do not insert any conductive objects into the sound box.

Do not disassemble.

Do not drop the product.

Keep out of reach of children.

Your BOOMPODS™ product is guaranteed against any defects in material or workmanship for one full year from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage such as a knock or immersion in water, etc.

The device must be used in accordance with the user manual. The warranty is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and tear or to any device that has been misused or tampered with. It should be returned to the local service centre, the service centre will not bear any shipping cost of the returned item.

Please check www.boompods.com for your local service centre.







1 - Power on/off 2 - Micro USB charging port 3 - LED indicator 4 - Speaker Bluetooth operation:

When using your downdraft speaker for the first time, please pair it with your mobile phone as follows:

- 1. Activate your phone's Bluetooth function and then enter its searching mode.
- 2. To switch on your downdraft speaker, push the on/off button (1) to "on", this will activate the Bluetooth function.
- 3. The LED (3) will flash alternately red and blue and a beep will indicate that the Bluetooth function has been successfully activated.
- 4. Your mobile phone will automatically find a new Bluetooth device called "DOWNDRAFT". Connect this device and a beep will indicate that the speaker has successfully been connected.
- 5. Please adjust the sound to a moderate volume and enjoy the music.
- 6. To switch off your downdraft speaker, push the on/off button (1) to "off".