


GS1200-5 / GS1200-8 5-Port / 8-Port Web Managed Gigabit Switch




Quick Start Guide

ENGLISH | DEUTSCH | FRANÇAIS | ITALIANO
ESPAÑOL | NEDERLANDS | DANSK | NORSK
SVENSKA | SUOMI

Package Contents


- Switch
- Power Adapter
- QSG
- Declaration of Conformity
Safety Warning

1 Hardware Installation



- EN** ① Connect to an appropriate power source.
② Connect to a modem or router that has internet access.
- DE** ① An eine geeignete Stromquelle anschließen.
② An ein Modem oder einen Router mit Internetanschluss anschließen.
- FR** ① Connectez-vous à une source d'alimentation appropriée.
② Connectez-vous à un modem ou un routeur ayant accès à Internet.
- IT** ① Collegare ad una fonte di alimentazione appropriata.
② Connettersi a un modem o router con accesso Internet.
- ES** ① Conecte a una fuente de corriente apropiada.
② Conectar a un módem o router con acceso a Internet.

2 Manage Your Device



- EN** ③ Connect your computer to the Switch using an Ethernet cable. Your computer must have an IP address in the same subnet as the Switch.
④ Launch your web browser and go to <http://192.168.1.3>. Enter 1234 as the password. Click **SIGN IN**.
- DE** ③ Verwenden Sie ein Ethernet-Kabel, um den Computer mit dem Switch zu verbinden. Ihr Computer muss eine IP-Adresse im gleichen Subnetz wie der Switch selbst haben.
④ Starten Sie Ihre Web Browser und gehen Sie auf <http://192.168.1.3>. Geben Sie admin als den Anwendernamen und 1234 als das Passwort ein. Klicken Sie auf **SIGN IN**.
- FR** ③ Connectez votre ordinateur au commutateur à l'aide d'un câble Ethernet. Votre ordinateur doit disposer d'une adresse IP dans le même sous-réseau que le commutateur.
④ Lancez votre navigateur web et allez à <http://192.168.1.3>. Entrez admin comme nom d'utilisateur et 1234 comme mot de passe. Cliquez sur **SIGN IN**.
- IT** ③ Collegare il computer allo Switch utilizzando un cavo Ethernet. Il computer deve avere un indirizzo IP nella stessa sottorete dello switch.
④ Avviare il browser e inserire l'indirizzo <http://192.168.1.3>. Immettere admin come nome utente e 1234 come password. Fare clic su **SIGN IN**.
- ES** ③ Conecte su ordenador al conmutador usando un cable Ethernet. Su ordenador debe tener una dirección IP en la misma subred que el conmutador.
④ Abra el navegador web y vaya a <http://192.168.1.3>. Escriba el nombre de usuario admin y la contraseña 1234. Haga clic en **SIGN IN**.

LEDs

PWR/SYS	Green	● On - Power on ● Blinking - Starting up
LINK/ACT	Amber	■ On - 10/100 Mbps connection ready ● Blinking - Data transmitting
	Green	■ On - 1000 Mbps connection ready ● Blinking - Data transmitting

Troubleshooting

- I cannot see or access the Login screen in the Web Configurator.**
- Make sure you are using the correct IP address. (The default IP address is 192.168.1.3.)
 - Make sure your computer is in the same subnet as the Switch. If you haven't changed the default IP address, your computer IP address should be in the 192.168.1.4 ~ 168.1.254 range.
 - Make sure you have entered the **Password** correctly. If you have changed the **Password** and have forgotten it, you'll have to reset the Switch to its factory default. (The default **Password** is 1234.)
- A loop is detected.**
- A loop may happen in the following example situations:
 - The Switch is connected to another device in a loop state.
 - The Switch is connected to another device with two cables.
 - Loop Prevention** is enabled by default. If a loop happens, the Switch will block the port in a loop state. If a loop happens on two ports, the Switch will block the higher-numbered port. For example, if a loop happens on ports 4 and 5, the Switch will block port 5, and its LED will be off. To restore a port in a loop state, disconnect it, check the network connections, and reconnect it.
 - You can log into the Web Configurator. Go to **System** in the Web Configurator to check your port status.

Your Networking Ally



Warranty Card

Thank you for purchasing a Zyxel product. Zyxel has a reputation for delivering high quality, high performance products and services to our customers. We recommend that you now visit the Zyxel website and register your product online. This will mean you can receive the latest firmware, drivers and product related information. If you still have further questions or enquiries related to the product, please contact our subsidiaries worldwide. Please note that warranty terms may vary by region. Full detailed information is available on our website, here: http://www.zyxel.com/support/warranty_information.shtml

Purchase Information

Zyxel Product Name: _____

Hardware Serial Number: _____

Date of Purchase: _____

(In certain countries, the warranty will be validated with seller's signature and stamp):

Support Information

- North America USA**
☎ + 1 800 255 4101
✉ support@zyxel.com
- France**
☎ + 33 (0)4 72 52 97 97
✉ support@zyxel.fr
- UK**
☎ + 44 (0) 118 9121 700
✉ support@zyxel.co.uk
- Italy**
☎ + 39 011 2308000
✉ support@zyxel.it
- Germany**
☎ + 49 (0) 2405 6909 0
✉ support@zyxel.de
- Spain**
☎ + 911 792 100
✉ soporte@zyxel.es

See the User's Guide at www.zyxel.com for more information, including customer support and safety warnings.

EU Importer
Zyxel Communications A/S
Generatorvej 8D, 2860 Søborg, Denmark.
<http://www.zyxel.dk>

US Importer
Zyxel Communications, Inc
1130 North Miller Street Anaheim, CA 92806-2001
<http://www.us.zyxel.com>

GS1200-5 / GS1200-8 5-Port / 8-Port Web Managed Gigabit Switch




Quick Start Guide

ENGLISH | DEUTSCH | FRANÇAIS | ITALIANO
ESPAÑOL | NEDERLANDS | DANSK | NORSK
SVENSKA | SUOMI

Package Contents


- Switch
- Power Adapter
- QSG
- Declaration of Conformity
Safety Warning

1 Hardware Installation



- NL** ① Sluit aan op een geschikte stroombron.
② Sluit aan op een modem of router met internetverbinding.
- DK** ① Tilslut til en relevant strømtilslutning.
② Tilslut til et modem eller router der har internetadgang.
- NO** ① Koble til en hensiktsmessig strømtilslutning.
② Koble til et modem eller en router som har Internet-tilgang.
- SE** ① Anslut till en lämplig strömkälla.
② Anslut till ett modem eller en router som har internetåtkomst.
- FI** ① Liitä laite yhteensopivaan virtalähteeseen.
② Liitä laite modeemiin tai reitittimeen, josta on Internet-yhteys.

2 Manage Your Device



- NL** ③ Sluit uw computer aan op de Schakelaar met een Ethernet-kabel. Uw computer dient een IP-adres te hebben in hetzelfde subnet als de Schakelaar.
④ Open uw webbrowser en ga naar <http://192.168.1.3>. Voer 1234 in als wachtwoord. Klik op **AANMELDEN**.
- DK** ③ Tilslut din computer til switchen ved brug af et Ethernet-kabel. Din computer skal have en IP-adresse i det samme undernet som switchen.
④ Start din webbrowser og gå til <http://192.168.1.3>. Indtast 1234 som adgangskode. Klik på **SIGN IN (Log på)**.
- NO** ③ Koble datamaskinen til bryteren ved hjelp av en Ethernet-kabel. Datamaskinen må ha en IP-adresse i samme subnett som bryteren.
④ Åpne nettleseren og gå til <http://192.168.1.3>. Angi 1234 som passord. Klikk på **LOGG PÅ**.
- SE** ③ Anslut datorn till switchen med en Ethernet-kabel. Datorn måste ha en IP-adress i samma subnet som switchen.
④ Starta din webbläsare och gå till sidan <http://192.168.1.3>. Skriv in 1234 som lösenord. Klicka på **LOGGA IN**.
- FI** ③ Liitä tietokone kytkimeen Ethernet-kaapelilla. Tietokoneen IP-osoitteen on oltava samassa aliverkossa kytkimen IP-osoitteen kanssa.
④ Avaa selain ja siirry osoitteeseen <https://192.168.1.3>. Kirjoita salasanaasi 1234. Valitse **SIGN IN (KIRJAUDU)**.

LEDs

PWR/SYS	Green	● On - Power on ● Blinking - Starting up
LINK/ACT	Amber	■ On - 10/100 Mbps connection ready ● Blinking - Data transmitting
	Green	■ On - 1000 Mbps connection ready ● Blinking - Data transmitting

Troubleshooting

I cannot see or access the Login screen in the Web Configurator.

- Make sure you are using the correct IP address. (The default IP address is 192.168.1.3.)
- Make sure your computer is in the same subnet as the Switch. If you haven't changed the default IP address, your computer IP address should be in the 192.168.1.4 ~ 168.1.254 range.
- Make sure you have entered the **Password** correctly. If you have changed the **Password** and have forgotten it, you'll have to reset the Switch to its factory default. (The default **Password** is 1234.)

A loop is detected.

- A loop may happen in the following example situations:
 - The Switch is connected to another device in a loop state.
 - The Switch is connected to another device with two cables.
- Loop Prevention** is enabled by default. If a loop happens, the Switch will block the port in a loop state. If a loop happens on two ports, the Switch will block the higher-numbered port. For example, if a loop happens on ports 4 and 5, the Switch will block port 5, and its LED will be off. To restore a port in a loop state, disconnect it, check the network connections, and reconnect it.
- You can log into the Web Configurator. Go to **System** in the Web Configurator to check your port status.

Your Networking Ally



Warranty Card

Thank you for purchasing a Zyxel product. Zyxel has a reputation for delivering high quality, high performance products and services to our customers. We recommend that you now visit the Zyxel website and register your product online. This will mean you can receive the latest firmware, drivers and product related information. If you still have further questions or enquiries related to the product, please contact our subsidiaries worldwide. Please note that warranty terms may vary by region. Full detailed information is available on our website, here: http://www.zyxel.com/support/warranty_information.shtml

Purchase Information

Zyxel Product Name: _____

Hardware Serial Number: _____

Date of Purchase: _____

(In certain countries, the warranty will be validated with seller's signature and stamp: _____)

Support Information

Netherlands
☎ +31 (0)88-00029112
✉ support@zyxel.nl

Finland
☎ + 358 9 4780 8400
✉ teknisk@zyxel.fi

Denmark
☎ + 45 30 55 07 00
✉ support@zyxel.dk

Norway
☎ + 47 22 80 61 80
✉ teknisk@zyxel.no

Sweden
☎ + 46 8 557 760 60
✉ support@zyxel.se

See the User's Guide at www.zyxel.com for more information, including customer support and safety warnings.

EU Importer
Zyxel Communications A/S
Generatorvej 8D, 2860 Søborg, Denmark.
<http://www.zyxel.dk>

US Importer
Zyxel Communications, Inc
1130 North Miller Street Anaheim, CA 92806-2001
<http://www.us.zyxel.com>

GS1200-5 / GS1200-8 5-Port / 8-Port Web Managed Gigabit Switch




Quick Start Guide

ČEŠTINA | SLOVENČINA | POLSKI | ROMÂNĂ
MAGYAR | SLOVENŠČINA | БЪЛГАРСКИ | TÜRK
ภาษาไทย | 繁體中文

Package Contents


- Switch
- Power Adapter
- QSG
- Declaration of Conformity
Safety Warning

1 Hardware Installation



- CZ** ① Připojte do odpovídajícího zdroje energie.
② Zapojte do modemu nebo směrovače s přístupem k internetu.
- SK** ① Pripojte k vhodnému zdroju napájania.
② Pripojte k modemu alebo smerovaču s prístupom do internetu.
- PL** ① Podłącz do odpowiedniego źródła zasilania.
② Podłącz do modemu lub routera z dostępem do Internetu.
- RO** ① Conectați la o sursă de alimentare corespunzătoare.
② Conectați la un modem sau router care este prevăzut cu acces la internet.
- HU** ① Csatlakoztasson egy megfelelő áramforrást.
② Csatlakoztasson egy internetkapcsolattal rendelkező modemet vagy útválasztót.

2 Manage Your Device



- CZ** ③ Kabelem sítě Ethernet připojte počítač nebo notebook k přepínači. Počítač musí mít stejnou IP adresu ve stejné podsíti jako přepínač.
④ Spusťte webový prohlížeč a přejděte na <http://192.168.1.3>. Jako heslo zadejte 1234. Klikněte na možnost **SIGN IN (Přihlásit se)**.
- SK** ③ Pomocou kábla siete Ethernet pripojte svoj počítač k zariadeniu Switch. Adresa IP vášho počítača musí byť v rámci rovnakej podsiete ako je zariadenie Switch.
④ Otvórz przeglądarkę internetową i wpisz adres <http://192.168.1.3>. Podaj hasło 1234. Kliknij **SIGN IN (zaloguj się)**.
- PL** ③ Podłącz komputer lub notebook do przełącznika, korzystając z kabla sieciowego. Komputer musi mieć adres IP w tej samej podsieci, co przełącznik.
④ Lansați navigatorul dvs. web și accesați <http://192.168.1.3>. Introduceți 1234 ca parolă. Dați clic pe **SIGN IN (AUTENTIFICARE)**.
- RO** ③ Conectați-vă computerul la Comutator cu ajutorul unui cablu Ethernet. Computerul dvs. trebuie să aibă o adresă IP în aceeași subrețea ca și Comutatorul.
④ Îndița el a webböngészőt és írja be a <http://192.168.1.3> címet. Adja meg az 1234 jelszót. Kattintson a **SIGN IN (bejelentkezés)** gombra.
- HU** ③ Csatlakoztassa számítógépét a switch-hez egy Ethernet kábelrel. Számítógépének a switch alhálózatához tartozó IP címmel kell rendelkeznie.
④ Spusťte webový prohlížeč a přejděte na <http://192.168.1.3>. Jako heslo zadejte 1234. Klikněte na možnost **SIGN IN (Přihlásit se)**.

LEDs

PWR/SYS	Green	● On - Power on ● Blinking - Starting up
LINK/ACT	Amber	■ On - 10/100 Mbps connection ready ● Blinking - Data transmitting
	Green	■ On - 1000 Mbps connection ready ● Blinking - Data transmitting

Troubleshooting

I cannot see or access the Login screen in the Web Configurator.

- Make sure you are using the correct IP address. (The default IP address is 192.168.1.3.)
- Make sure your computer is in the same subnet as the Switch. If you haven't changed the default IP address, your computer IP address should be in the 192.168.1.4 ~ 168.1.254 range.
- Make sure you have entered the **Password** correctly. If you have changed the **Password** and have forgotten it, you'll have to reset the Switch to its factory default. (The default **Password** is 1234.)

A loop is detected.

- A loop may happen in the following example situations:
 - The Switch is connected to another device in a loop state.
 - The Switch is connected to another device with two cables.
- Loop Prevention** is enabled by default. If a loop happens, the Switch will block the port in a loop state. If a loop happens on two ports, the Switch will block the higher-numbered port. For example, if a loop happens on ports 4 and 5, the Switch will block port 5, and its LED will be off. To restore a port in a loop state, disconnect it, check the network connections, and reconnect it.
- You can log into the Web Configurator. Go to **System** in the Web Configurator to check your port status.

Your Networking Ally



Warranty Card

Thank you for purchasing a Zyxel product. Zyxel has a reputation for delivering high quality, high performance products and services to our customers. We recommend that you now visit the Zyxel website and register your product online. This will mean you can receive the latest firmware, drivers and product related information. If you still have further questions or enquiries related to the product, please contact our subsidiaries worldwide. Please note that warranty terms may vary by region. Full detailed information is available on our website, here: http://www.zyxel.com/support/warranty_information.shtml

Purchase Information

Zyxel Product Name: _____

Hardware Serial Number: _____

Date of Purchase: _____

(In certain countries, the warranty will be validated with seller's signature and stamp):

Support Information

Czech
☎ + 420 241 774 665
✉ support@cz.zyxel.com

Hungary
☎ + 36 1 848 0690
✉ support@zyxel.hu

Slovakia
☎ + 421 220 861 848
✉ soporte@sk.zyxel.com

Poland
☎ + 48 22 652 16 26
✉ support@pl.zyxel.com

Romania
✉ info@ro.zyxel.com


See the User's Guide at www.zyxel.com for more information, including customer support and safety warnings.

EU Importer
Zyxel Communications A/S
Generatorvej 8D, 2860 Søborg, Denmark.
<http://www.zyxel.dk>

US Importer
Zyxel Communications, Inc
1130 North Miller Street Anaheim, CA 92806-2001
<http://www.us.zyxel.com>

ZYXEL

GS1200-5 / GS1200-8 5-Port / 8-Port Web Managed Gigabit Switch




Quick Start Guide

ČEŠTINA | SLOVENČINA | POLSKI | ROMÂNĂ
MAGYAR | SLOVENŠČINA | БЪЛГАРСКИ | TÜRK
ภาษาไทย | 繁體中文

Package Contents


- Switch
- Power Adapter
- QSG
- Declaration of Conformity
Safety Warning

1 Hardware Installation



- SL** ① Přiklučíte v ustrezno električno vtičnico.
② Povežite na modem ali usmerjevalnik, ki ima internetni dostop.
- BG** ① Свържете към подходящо захранване.
② Свържете към модел или рутер, който има интернет достъп.
- TR** ① Uygun bir güç kaynağına bağlayın.
② İnternet erişimi olan bir modeme veya yönlendiriciye bağlayın.
- TH** ① เชื่อมต่อไปยังแหล่งจ่ายไฟที่เหมาะสม
② เชื่อมต่อกับโมเด็มหรือเราเตอร์ที่มีการเข้าถึงอินเทอร์เน็ต
- TW** ① 連接至適當的電源插座。
② 連接至可存取網際網路的數據機或路由器。

2 Manage Your Device



- SL** ③ Z ethernetnim kablom povežite računalnik na Switch. Računalnik mora imeti naslov IP v istem podmrežju, kot ga ima Switch.
④ Zaženite spletni brskalnik in odprite <http://192.168.1.3>. Vnesite geslo 1234. Kliknite **PRIJAVI**.
- BG** ③ Свържете Вашият компютър към суича с помощта на Ethernet кабел. Вашият компютър трябва да има IP адрес в същата подмрежа като суича.
④ Отворете браузъра и отидете на <https://192.168.1.3>. Въведете 1234 като парола. Цракнете **ВХОД**.
- TR** ③ Bilgisayarınızı bir Ethernet kablosu kullanarak Anahtara bağlayın. Bilgisayarınız, Anahtarla aynı alt ağdaki bir IP adresine sahip olmalıdır.
④ Web tarayıcınızı başlatıp <http://192.168.1.3> adresine gidin. Şifre olarak 1234 girin. **SIGN IN (OTURUM AÇ)** düğmesine tıklayın.
- TH** ③ เชื่อมต่อคอมพิวเตอร์กับสวิตช์โดยใช้สายเคเบิลอีเธอร์เน็ต คอมพิวเตอร์ของคุณต้องมีที่อยู่ IP ในเครือข่ายย่อยเช่นเดียวกับสวิตช์ เปิดเว็บเบราว์เซอร์ของคุณและไปที่ <http://192.168.1.3> ป้อนรหัสผ่าน 1234 คลิก **SIGN IN (ลงชื่อเข้าใช้งาน)**
- TW** ③ 用乙太網路線將電腦連接至交換器。您電腦的 IP 位址必須與交換器位在同一個子網域。
④ 啟動您的網頁瀏覽器，並前往 <http://192.168.1.3>。輸入密碼 1234 並登入。

LEDs

LED	Color	Meaning
PWR/SYS	Green	● On - Power on
	Green	● Blinking - Starting up
LINK/ACT	Amber	● On - 10/100 Mbps connection ready
	Amber	● Blinking - Data transmitting
	Green	● On - 1000 Mbps connection ready
LINK/ACT	Green	● Blinking - Data transmitting

Troubleshooting

I cannot see or access the Login screen in the Web Configurator.

- Make sure you are using the correct IP address. (The default IP address is 192.168.1.3.)
- Make sure your computer is in the same subnet as the Switch. If you haven't changed the default IP address, your computer IP address should be in the 192.168.1.4 ~ 168.1.254 range.
- Make sure you have entered the **Password** correctly. If you have changed the **Password** and have forgotten it, you'll have to reset the Switch to its factory default. (The default **Password** is 1234.)

A loop is detected.

- A loop may happen in the following example situations:
 - The Switch is connected to another device in a loop state.
 - The Switch is connected to another device with two cables.
- Loop Prevention** is enabled by default. If a loop happens, the Switch will block the port in a loop state. If a loop happens on two ports, the Switch will block the higher-numbered port. For example, if a loop happens on ports 4 and 5, the Switch will block port 5, and its LED will be off. To restore a port in a loop state, disconnect it, check the network connections, and reconnect it.
- You can log into the Web Configurator. Go to **System** in the Web Configurator to check your port status.

ZYXEL

Your Networking Ally



Warranty Card

Thank you for purchasing a Zyxel product. Zyxel has a reputation for delivering high quality, high performance products and services to our customers. We recommend that you now visit the Zyxel website and register your product online. This will mean you can receive the latest firmware, drivers and product related information. If you still have further questions or enquiries related to the product, please contact our subsidiaries worldwide. Please note that warranty terms may vary by region. Full detailed information is available on our website, here: http://www.zyxel.com/support/warranty_information.shtml

Purchase Information

Zyxel Product Name: _____
Hardware Serial Number: _____
Date of Purchase: _____
(In certain countries, the warranty will be validated with seller's signature and stamp: _____)

Support Information

- Bulgaria**
✉ support@zyxel.bg
- Turkey**
☎ + 90 212 444 11 50
✉ bilgi@Zyxel.com.tr
- Thailand**
☎ + 66 2831 5315
✉ support@zyxel.co.th
- Taiwan**
☎ + 886 2 2739 9889
✉ retail@zyxel.com.tw

See the User's Guide at www.zyxel.com for more information, including customer support and safety warnings.

EU Importer
Zyxel Communications A/S
Generatorvej 8D, 2860 Søborg, Denmark.
<http://www.zyxel.dk>

US Importer
Zyxel Communications, Inc
1130 North Miller Street Anaheim, CA 92806-2001
<http://www.us.zyxel.com>

Copyright © 2017 Zyxel Communications Corp. All Rights Reserved.